




















Assembly instruction for Elizabeth Wood LS-623

1		left arm	1pc
2		mid arm	1pc
3		right arm	1pc
4		back bracket	4pcs
5		left end panel	1pc
6		right end panel	1pc
7		outer back panel	2pcs
8		back cushion	2pcs
9		seat cushion	2pcs
10		anchor bolt cap	8pcs
11		anchor bolt	8pcs
12		M6 nut	6pcs
13		hexagon screw M6x14	8pcs
14		philip screw M6x16	4pcs
15		philip screw M6x14	6pcs
16		back hook	6pcs
17		philip screw ST4x16	12pcs
18		connecting plate for back	4pcs
19		hexagon screw M8x20	4pcs
20		hexagon screw M6x20	2pcs

