



X1-1 Drukknemer +
 X1-2 Drukknemer NC
 X1-3 Drukknemer NO
 X1-4 Rookmelder NO
 X1-5 + X1-6 & 7
 X1-6 Aanwezigheids sensor
 X1-7 Temp. binnen
 X1-8 Temp. binnen
 X1-9
 X1-10
 X1-11 lichtschakelaar
 X1-12

X2-1 geen storing
 X2-2 +48Vdc
 X2-3 storing
 X2-4 Temp. <40C°
 X2-5 +48Vdc
 X2-6 Temp. >40C°
 X2-7 Temp. >5C°
 X2-8 +48Vdc
 X2-9 Temp. < 5C°
 X2-10 Rookmelder NO
 X2-11 +48Vdc
 X2-12 Rookmelder NC

X3-1 vent. Sturing. 0->10Vdc +
 X3-2 vent. Sturing. 0->10Vdc -
 X3-3 verl. 0 <->10Vdc +
 X3-4 verl. 0 <->10Vdc -